



# TASKI® YELLOW Maintenance Points

Yellow indicates a component of the machine that is recommended to clean after each use.



### Large Debris Filter

Empty large items into the trash and rinse thoroughly.



### Recovery Tank/Vacuum Filter

Remove the recovery tank/vacuum filter from machine. Rinse and clean dirt and debris from the filter.



### Squeegees

Disconnect the squeegee assembly from the autoscrubber. Rinse the squeegee and wipe clean. Hair and other debris left on the squeegees may hinder results by leaving streaks or misses on the floor.



### Pads & Brushes

Remove pads or brushes from the machine. Rinse thoroughly and replace as needed.



### Solution Filter

The solution filter can be found near the bottom of the machine. Un-screw the cap and remove the filter from the machine and rinse thoroughly.

Maintenance  
Points  
Video



SCAN ME

ATTENTION! Do not use the machine before you have read and understand the operating instructions.

TASKI®